



Industry Line

Deter Cat

Technical Sheet n° 048
Rev. 14/05/2014

Category:

- Detergent for the industrial sector

Applications:

- Removes all residues from stenters

Strengths:

- Great effectiveness in cold water
- Concentrated product

Product for professional use. The manufacturer declines all responsibility for any damage caused by the improper use of the product.

Highly effective detergent for stenter chains cold-water washing

Applications

Deter Cat is a highly concentrated detergent for cold-water washing of stenters' chains (not made of aluminum or other alloys).

Deter Cat drastically reduces manual interventions in washing operations of the stenters' chains as, thanks to its effectiveness, it removes the greasy dirt accumulated on them because of the heat they are exposed to.

Deter Cat is extremely easy to use.

How to use

Dilute the product with cold water in the proportion 1:1. Dip the chains in the solution obtained for a time varying from 12 to 18 hours. Pull the chains out the solution and rinse accurately, preferably with a high pressure water jet (high pressure cleaner), until the total elimination of all remains.

After having washed, lubricate the chains.

Do not use on aluminum or other light alloys.

Technical specifications

pH	>13
Smell	Characteristic
Color	Yellow
Density (20°C)	1,220 g/cm ³