



Industry Line

HB 34

Technical Sheet n° 084
Rev. 27/01/2017

Detergent for aluminium rapiers and stenter frames

Category:

- Products for the maintenance of textile equipment

Applications:

- Cleaning of aluminium rapiers and stenters' chains

Strenghts:

- Great effectiveness
- Reusable

Applications

HB 34 is formulation with both detergent and solvent synergetic action.

Thanks to its high concentration of surfactants and solvents, HB 34 is highly effective on heavy dirt and grimes that accumulates on rapiers and on stenter frames during tissue processing.

HB 34 emulsifies and completely dissolves at room temperature oils, grease, grimes derived from processing and residues that are difficult to remove with normal alkaline products.

How to use

HB 34 can be used raw or diluted with water up to 30%. The choice between raw use and dilution depends on the consistency of the dirt to be removed.

We suggest to dip the parts to be treated into the solution and to let them submerged for a time comprised between 8 and 15 hours.

Subsequently, rinse accurately the treated pieces, preferably with a high pressure water jet.

The solution can be used many times, until the dirt has completely contaminated it. If you can not unmount the stenter frames, spray the pure product (or diluted 1:1) several times directly on the part to be treated, leave the necessary time, then rinse thoroughly.

Technical specifications

Product for professional use. The manufacturer declines all responsibility for any damage caused by the improper use of the product.

pH	13
Smell	Characteristic
Color	Blue
Density (20°C)	1,020 g/cm ³